

Tent-Style Favor Box

Assembly Instructions

- 1 Open folded box into a rectangle.



- 2 Fold in the two side flaps of the bottom at the scored lines.



- 3 Fold down scored tabs and tuck into the bottom of box. Fold the large bottom flap over.



- 4 Pinch sides of box together to crease the scored lines on the sides which will fold in toward the inside of the box. Fold the patterned lid down at scored line.



- 5 Thread the included, pre-cut ribbon into one of the pre-punched slots in the top flap, coming from the back



- 6 Using included, pre-cut ribbon, loosely thread ribbon through one hole in the front, coming from the back.



- 7 Carefully pull ribbons tight while pressing scalloped flap closer to box.



- 8 Tie the ribbon in a bow to complete favor.



You're done!

Guests will be so impressed with your beautiful party decor.

